

Traxda 601040 Installation Instructions

- Grand Cherokee
- Dodge Durango

Tools required:

- Strut compressor
- hand tools
- floor jack and stands

ALWAYS BE SAFE! USE JACK STANDS, BE CAREFUL WITH SPRING COMPRESSOR

1. Jack up vehicle, place on jack stands. Always place a jackstand under the rear bumper, this will help in re-installing the struts.
2. Install one side at a time
3. Remove wheel
4. Remove sway bar link
5. Remove CV joint nut, to allow suspension to droop fully. Push into hub
6. Separate the upper ball joint
7. Remove lower strut mount bolts
8. Remove upper strut mount nuts, remove strut from vehicle

ALWAYS MAKE SURE TO SUPPORT SPINDLE, DO NOT DAMAGE WIRES OR BRAKE LINES

1. Using a strut compressor, disassemble strut.
2. Install preload spacer
3. Reassemble strut.
4. Re-install strut into vehicle and repeat above steps in reverse

TroubleShooting

Q. I hear a clunk over bumps

A. Check your sway bar links, loose mounts are a common cause of clunk

Q. I can't get the ball joint to install into the upper control arm.

A. Support the rear bumper, this makes using a prybar more effective on the front axle.