

## **Installation Instructions - Kit # 605041- 2014 Dodge Ram 2500 4x4 1" Rear Lift Kit**

When installing the rear spacer, install one side at a time.

Check for ABS wiring issues before lowering axle!

Remove shock lower bolt from one side at a time.



Raise rear of vehicle and support with jackstands at frame on both sides. Remove wheels, support axle on one side and remove the lower shock mounting bolt.

Spring isolator is located at the top of the spring.



Traxda spacer goes on top of OEM spring isolator as shown.

Re-install spring with Traxda spacer on top of isolator

Re-install shock



Repeat steps on the other side of the vehicle.  
Then recheck all work, and reinstall wheels.  
Lower vehicle back to the ground.  
Once work is completed have a trained technician perform an alignment.