



Rev. # 7-04

PART #SE2000\SE2007

Chevy Suburban,Tahoe,Avalance Rear Lower Shock Extenders

INSTALLATION INSTRUCTIONS

Please take the time to read these **INSTALLATION INSTRUCTIONS** and check the **Hardware Parts List** to be sure you have all the listed parts.

These installation instructions are prepared for the professional installer with the proper equipment, tools and experience in suspension systems and safety. This vehicle and its components are extremely heavy and can be dangerous without the proper equipment and experience.

Please read the warranty information (blue page enclosed). Complete your **Product Warranty Card** and mail it to DJM Suspension.

Please take a few minutes to fill out your installation helper (back side of warranty). **Accurate measurements BEFORE BEGINNING INSTALLATION** will show any irregularities in your vehicle.

NEVER WORK UNDER TRUCK SUPPORTED BY A JACK ONLY !!!
USE QUALITY JACK STANDS WHICH HAVE A RATING ADEQUATE FOR YOUR TRUCKS WEIGHT!!!

Hardware Parts List:

- 2- Lower Shock Extenders.
- 2- Threaded Reinforcement Plates.
- 4- 1/2" x1 Bolts.
- 4- 1/2" Jam Nuts.
- 2- 1/2 x 13 x 1-1/4" Bolts.
- 6- 1/2" Flat Washers.
- 6- 1/2" Lock Washers.

Line up the holes in the shock extender with the factory shock mount.

Using the 1/2" x 1" bolts attach shock extender to factory shock mount, use a flat washer and lockwasher on each bolt. Nuts will go on the inside.

Use one 1/2" x 1-1/4 bolt through the cross brace and attach to the treaded reinforcement plate on the back side of the factory mount.

Attach shock to new shock extender using original bolts.

