



PART # CB31

Carrier Bearing Bracket

1983-1997 Ford Ranger Extended Cab

INSTALLATION INSTRUCTIONS

Rev. # 3-03

Please take the time to read these INSTALLATION INSTRUCTIONS and check the Hardware Parts List to be sure you have all the listed parts.

These installation instructions are prepared for the professional installer with the proper equipment, tools and experience in suspension systems and safety.

Hardware Parts List:

2- 3/8" Shim Plates.

2- 3/8" x 2-1/4" Bolts w\ nuts and washers.

Vehicles with 2 piece drive shafts may experience drive line vibration at low speeds and will need to raise the carrier bearing.

The bearing is bolted to the cross member and needs to be raised up.

Place the shims between the bearing and the cross member. Install new bolts and tighten.

Test drive. If vibration is still present add a few flat washers to raise the bearing a bit more.