

FRONT

1. Pull windshield wiper arms
2. Pull cowl cover
3. Remove windshield wiper motor
4. Remove 3 nuts on the top of each strut
5. Remove axle nut - IMPORTANT
6. Remove 12 mm bolt holding brake line on
7. Remove 10 mm bolt holding ABS wire
8. Remove sway bar link at the strut
9. Remove two lower strut bolts
10. CAREFUL - parts will be unsupported - remove from vehicle

11. Install Traxda strut spacer on to strut.

12. Rotate strut hat 180 degrees

13. Reinstall strut with lower bolts.
14. Re attach sway bar link
15. Reattach brake line
16. Re attach 3 bolts on strut and reinstall all other parts.

Alignment - use #81260 for Camber adjustment if necessary

REAR

1. Remove lower shock bolt
2. Remove lower strut bolt
3. Loosen rear suspension arm bushing
4. Place Traxda coil spring spacer on top of spring, on top of spring isolator
- 5.
6. Rear shock spacer (if applicable)
7. Open rear hatch
8. Move seat forward
9. Open the small plastic panel near floor and remove top shock nut
10. Remove shock from vehicle.
11. Install ½ thick washer on top of shock to make it slightly longer, install on top of shock
12. Re install shock into van.

Reverse the steps during reinstallation

Make sure to tighten rear suspension bushing when vehicle is on the ground. Tightening while in the air could result in premature bushing wear.