

### FORD 2015-20 F-150 Hood/Ditch Light Mount

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Periodically check all hardware for tightness.

**KIT CONTENTS:**

- Driver Side Ditch Light Mount x1
- Pass Side Ditch Light Mount x1

**TOOLS NEEDED:**

- 10mm Socket
- 14mm Socket/Wrench



**Torque Specs:**

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs



## INSTALLATION INSTRUCTIONS

1. Pull back the side of the wiper cowl. **NOTE: Be careful with plastic clip. See Photo 1.**
2. Remove the upper fender bolt under the cowl using a 10mm socket. **See Photo 2.**



3. Install the driver side mounting bracket (bracket should swing towards the back) and retighten the stock bolt. **See Photo 3.**
4. Install the cube light with the bolts supplied with the light using a 14mm wrench. **See Photo 4.**



5. Run the wire underneath the cowl to the engine compartment. **NOTE: Make sure wire won't be damaged. See Photo 5.**
6. Refer to the instructions that came with the light to wire it to the vehicle.

