

## #109030 REAR INSTALLATION

1. remove inside control arm bolt, after marking alignment cams.
2. Swing arm down, remove spring (compressor may be useful)
3. Remove bumpstop with T45 torx
4. Install Traxda spring spacer
5. reinstall bump stop
6. reinstall spring
7. reinstall control arm bolt. Use tall jack stand and spring compressor to get things together
8. Align to factory spec