

PART NO. 72045

SPC
PERFORMANCE

Instruction Sheet

MUSTANG REAR ADJUSTABLE PANHARD BAR

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

**Check out how to install this part at:
<http://spc-tv.com>**



This control arm replaces the stock lower panhard bar.

1. Raise rear of vehicle and support by body so suspension hangs free.
2. Remove bar by removing both retaining bolts.
3. Adjust new bar so equal threads are showing on both ends and bar is same length as OE stock bar.

NOTE: Maximum bar length is reached when machined flat on threaded rod is visible at end of hex adjuster center section. DO NOT lengthen bar beyond this point.

4. Install new bar onto vehicle.
5. Lower vehicle before tightening control arm retaining bolts to manufacturer's specifications. Make sure suspension is loaded before tightening retaining bolts.
6. Adjust bar to attain lateral offset desired. Tighten lock nuts on ends of panhard bar.

Always check for proper clearance between suspension components and other components of the vehicle.



**Specialty
Products
Company**

4045 Specialty Pl. • Longmont, CO 80504 • (303) 772-2103
www.specprod.com • Email: info@specprod.com ECN#2702

Toll Free Technical Hot Line: 1-800-525-6505 Printed in U.S.A

For warranty information go to: www.specprod.com/warranties

©2019 Niwot Corp. dba Specialty Products Co.® • Form No.72045INS • Rev 8/19