

Installation Instructions - Kit # 202028 Honda Oddysey

1



Raise vehicle on jack stands and remove wheels. Disconnect the ABS and brake hose.

2



VERY IMPORTANT! Loosen & remove the axle nut, and push the axle through the spindle to allow suspension to droop

3



Disconnect sway bar end link from strut.

4



Disconnect tie rod end.

5



Remove the lower strut mounting bolts from the spindle. you may need to carefully tap the bolts with a hammer to fully remove them.

Remove nuts from upper strut mount. Support weight of strut before removing final nut. Remove strut from vehicle.

7

8

Install spacer on strut using factory nuts.

Installation Instructions Ctd. - Kit # 202028 Honda Oddysey

Reinstall upper strut mounting nuts. Do not tighten fully.



Install Traxda sway bar extension bracket with provided hardware. Tighten the sway bar end link to the Traxda bracket.

Check all hardware is mounted at correct torque settings. Recheck all work, and reinstall wheels. Once back on the ground, have a trained technician perform an alignment.

10



Reinstall lower strut mounting bolts while guiding axle through the spindle. Tighten all strut nuts fully, upper and lower.

12



Re-tighten the axle nut, reinstall the tie rod (above) and the ABS/ brake lines.

	Left	Right
Camber	-0.25	-0.25
Caster		
Total Toe	0	



Mark bolt, so that your camber does not change



Loosen bolt, but do not remove



Remove lower arm bolt



Lower carefully with floorjack



Put Traxda spacer on top of rubber



Make sure notch goes to correct place



Use jack to lift arm back into place.

Tighten inside suspension arm bolt when vehicle is on the ground under full weight.