

PART NO. 67245

Instruction Sheet

HONDA BALL JOINT

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

1. Prior to installing the ball joint pay close attention to the “*alignment indicator marks*” on either the #62030 adjustable control arm, or the OE non-adjustable control arm.
2. Remove any existing ball joint (if applicable) by first removing the boot and snap ring from the ball joint, then press the ball joint out of the control arm.
3. Align the “*indicator marks*” on both the control arm and the ball joint, then press the ball joint into the control arm.

Always check for proper clearance between suspension components and other components of the vehicle.

4. Reinstall the snap ring, the boot and the retaining clip onto the ball joint.
-



**Specialty
Products
Company**[®]

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103

www.specprod.com • www.spcperformance.com

Email: info@specprod.com

Toll Free Technical Hot Line: 1-800-525-6505

©2004 Specialty Products Co. • Printed in U.S.A. • Form No. 98245 • Rev. 10/04