

300 HUEY LENARD LOOP | WEST MONROE | LA 71292 OFFICE: 318-397-3000 | FAX: 318-397-3040 SERVICE & TECH SUPPORT: 800-551-4955 SUPERLIFT.COM

2021 BRONCO SPORT 4WD

1.5" Lift Kit INSTALLATION INSTRUCTIONS





INTRODUCTION

Prior to beginning the installation, OPEN the Boxes and CHECK the Included Components Compared to the Parts Breakdown. Check all parts and hardware in the box with the parts list below. Be sure you have all needed parts and know where they install.

IF you find a packaging error, contact SUPERLIFT directly. Do not contact the dealer where the system was originally purchased. You will need the control number from each box when calling; this number is located at the bottom of the part number label and to the right of the bar code.

PARTS LIST ... The part number is stamped into each part or printed on an adhesive label. Identify each part and place the appropriate mounting hardware with it.

Installation requires a professional mechanic. The overall vehicle must be in excellent working condition; repair or replace all worn parts.

Read instructions several times before starting. Be sure you have all needed parts and know where they install. Read each step completely as you go.

NOTES:

- Front end alignment is necessary.
- A foot-pound torque reading is given in parenthesis () after each appropriate fastener.
- Do not fabricate any components to gain additional suspension height.
- Prior to attaching components, be sure all mating surfaces are free of grit, grease, excessive undercoating, etc.
- A factory service manual should be on hand for reference.

KIT BREAKDOWN						
Qty.	Description					
4	Rear Control Arm Spacers					
2	Front Strut Spacer					
2	Rear Coil Spring Spacers					
2	Front Sway Bar Bracket					
2	Front Sway Bar Links					
1	Hardware Bag: Kit					
	Qty. 4 2 2 2 2					

Step	Part Number	Qty. Per Kit	Description	New Attaching Hardware	Qty. Per Bracket	Hardware Bag Number		
FRONT								
14	55-01-9750	-9750 2 Front Strut	Front Strut Spacer	8mm x 25mm bolt, 1.25 pitch	3	77-9750		
				8mm washer	3			
				8mm lock washer	3			
23 55-0	55-03-9750	2	Front Sway Bar Bracket	12mm x 40mm bolt, 1.75 pitch	1	77-9750		
				12mm washer	1			
				12mm flange nut, 1.75 pitch	1			
24	MS90841	2	Front Sway Bar Links					
REAR								
9	05-9755	4	Rear Control Arm Spacers	14mm x 60mm bolt, 2.0 pitch	1	77-9750		
				14mm washer	1			
				14mm lock washer	1			
11	55-02-9750	2	Rear Coil Spring Spacers					

Save all factory components and hardware for reuse, unless noted.


- 1. Disconnect the battery.
- 2. [Illustration 1] Under the hood, remove clip holding the windshield wiper cover.
- 3. [Illustration 1] Lift the windshield wiper cover, then unbolt and remove the strut cover.
- 4. [Illustration 2] Unbolt the upper strut bolts. [13mm]






- 5. Secure the vehicle on jack stands with a jack under the lower control arm.
- 6. Remove front tires.
- 7. [Illustration 3] Disconnect the tie rod from the knuckle. [15mm]
- 8. [Illustration 4] Remove and discard the sway bar link. [18mm]





- 9. [Illustration 5 &6] Disconnect the ABS sensor plug from the sensor and unclip the ABS wire from the strut and the body in two places behind the strut.
- 10. [Illustration 7] Remove the brake hose from the strut. [8mm]
- 11. [Illustration 8] Remove the bolts from the lower strut mount. [21mm]
- 12. [Illustration 9] Carefully lower the control arm enough to remove the strut from the vehicle.

FORM#9750.01-030822 PRINTED IN U.S.A. PAGE 4 OF 10













- 13. [Illustration 10 & 11] Using the appropriate sanding tool, grind the lower strut edge down; paint the ground edge.
- 14. [Illustration 12] Place the new strut spacer (55-01-9750) on the top of the strut and secure using the factory hardware.
- 15. [Illustration 13] Install the strut back into the vehicle.
- 16. Raise the control arm up to seat the upper strut mount in position and secure the upper mount using the supplied 8mm hardware. [13mm]





- 17. Reinstall the strut cover using the factory hardware.
- 18. Reclip the windshield wiper cover.
- 19. Secure the lower mount using the factory hardware. [21mm]
- 20. Reattach the brake hose to the bracket using the factory hardware. [8mm]
- 21. [Illustration 14 & 15] Route the ABS wire between the brake hose and the bracket and around the outside of the strut body. Clip the ABS wire back into the clip on the lower strut mount and reconnect the plug to the sensor.
- 22. [Illustration 15 & 16] Using the supplied zip ties, secure the ABS wire to the shock body as well as the brake hose bracket.









- PRINTED IN U.S.A. 23. [Illustration 17] Install the new sway bar bracket (55-03-9750) and secure the bracket to the stock location using the supplied 12mm hardware placing the bolt from the inside facing out. [19mm]
- 24. [Illustration 18] Attach the new sway bar links (MS90841) to the new bracket and the factory sway bar body using the supplied hardware. [19mm]
- 25. Reattach the tie rod end to the knuckle. [15mm]



- 26. Reinstall the tires and wheels. Tighten the lug nuts.
- 27. When the tires / wheels are installed, always check for and remove any corrosion, dirt, or foreign material on the wheel mounting surface, or anything that contacts the wheel mounting surface (hub, rotor, etc.). Installing wheels without the proper metal-to-metal contact at the wheel mounting surfaces can cause the lug nuts to loosen and the wheel to come off while the vehicle is in motion.
- 28. Retighten lug nuts at 500 miles after any wheel change, or anytime the lug nuts are loosened. Failure to do so could cause wheels to come off while vehicle is in motion.
- 29. With the vehicle still on jack stands, and the suspension "hanging" at full extension travel, check all components for proper operation and clearances. Pay special attention to clearance between the tires / wheels and brake hoses, driveshaft, etc.
- 30. Lower vehicle to the floor.

REAR INSTALLATION

- 1. Secure the vehicle on jack stands with a jack under the lower control arm.
- 2. Remove rear tires.
- 3. [Illustration 1] Remove the bolts holding the sound dampening liner in place.
- 4. [Illustration 2] Disconnect the lower mount of the sway bar link. [18mm]





- 5. [Illustration 3] Remove the lower shock bolt. [15mm]
- 6. Loosen but do not remove the upper control arm bolt at the knuckle. [15mm]
- 7. [Illustration 4] Remove the lower bolt control arm bolt at the knuckle. [15mm]
- 8. [Illustration 4] Lower the lower control arm enough to remove the coil spring from the vehicle.





- 9. [Illustration 5] Remove the link arm bolts from the frame, place a new spacer (05-9755) between the link arm and the frame and secure the link arm and spacers using the supplied 14mm hardware. [21mm]
- 10. [Illustration 6] Remove the coil spring isolator from the lower control arm.
- 11. [Illustration 6] Install the new coil spring spacer (55-02-9750) onto the lower control arm locating the pin in the factory location on the control arm.

FORM#9750.01-030822 PRINTED IN U.S.A. PAGE 8 OF 10





- 12. [Illustration 7] Place the coil spring isolator on the top of the new coil spring spacer.
- 13. [Illustration 7] Reinstall the coil spring and raise the lower control arm to hold the coil in place.
- 14. Reinstall the lower control arm bolt.
- 15. Reinstall the lower shock bolt.
- 16. Reattach the sway bar link.
- 17. Tighten the upper control arm bolt.
- 18. Reinstall the tires and wheels. Tighten the lug nuts.
- 19. When the tires / wheels are installed, always check for and remove any corrosion, dirt, or foreign material on the wheel mounting surface, or anything that contacts the wheel mounting surface (hub, rotor, etc.). Installing wheels without the proper metal-to-metal contact at the wheel mounting surfaces can cause the lug nuts to loosen and the wheel to come off while the vehicle is in motion.
- 20. Retighten lug nuts at 500 miles after any wheel change, or anytime the lug nuts are loosened. Failure to do so could cause wheels to come off while vehicle is in motion.



PRINTED IN U.S.A.

- 1. Check all hardware for proper torque specifications.
- 2. With the vehicle on the ground, check all components for proper operation and clearances. Pay special attention to the clearance between the tires / wheels, brake hoses, wiring, etc. Check tire/ wheel clearance with the fenders/bumper as well as with the steering knuckle.
- Realign vehicle to factory OEM specifications. It is necessary to have a proper and professional
 wheel alignment performed by a certified alignment technician. Align the vehicle to factory
 specifications. It is recommended that your vehicle alignment be checked after any off-road
 driving.
- 4. Re-adjust headlights to proper setting. In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle head lamps for proper aim and alignment.
- 5. Activate four wheel drive system and check for proper engagement.
- 6. Install the **Warning to Driver** decal on the inside of the windshield or dash within the driver's view.

IMPORTANT MAINTENANCE INFORMATION

It is the ultimate buyer's responsibility to have all bolts / nuts checked for tightness after the first 100 miles and then every 1000 miles. The steering, suspension and driveline systems, plus wheel alignment should be inspected by a qualified professional mechanic at least every 3000 miles.

LIMITED LIFETIME WARRANTY / WARNINGS

Your SUPERLIFT® product is covered by the Limited Warranty explained below that gives you specific legal rights. This limited warranty is the only warranty SUPERLIFT® makes in connection with your product purchase. SUPERLIFT® neither assumes nor authorizes any retailer or other person or entity to assume for it any other obligation or liability in connection with this product or limited warranty.

SUPERLIFT, LLC, LIMITED LIFETIME WARRANTY

What is covered? Subject to the terms below, SUPERLIFT® will repair or replace its products found defective in materials or workmanship for so long as the original purchaser owns the vehicle on which the product was originally installed. Your warranter is SUPERLIFT, LLC, doing business as SUPERLIFT® Suspension Systems ("SUPERLIFT®").

What is not covered? Your SUPERLIFT® Limited Warranty does not cover products SUPERLIFT® determines to have been damaged by or subjected to:

- Alteration, modification or failure to maintain.
- Normal wear and tear (bushings, rod ends, etc.). Scratches or defects in product finishes (powder coating, plating, etc.).
- Damage to, or resulting from, the vehicle's electronic stability system, related components or other vehicle systems.
- Racing or other vehicle competitions or contests. Accidents, impact by rocks, trees, obstacles or other aspects of the environment.
- Theft, vandalism or other intentional damage.

Remedy Limited to Repair or Replacement. The exclusive remedy provided hereunder shall, upon

SUPERLIFT's inspection and at SUPERLIFT's option, be either repair or replacement of the product covered under this Limited Warranty. Customers requesting warranty consideration should contact SUPERLIFT® by phone (1-800-551-4955) to obtain a Returned Goods Authorization number. All removal, shipping and installation costs are customer's responsibility.

If a replacement part is needed before the SUPERLIFT® part in question can be returned, you must first purchase the replacement part. Then, if the part in question is deemed warrant-able, you will be credited / refunded.

OTHER LIMITATIONS - EXCLUSION OF DAMAGES - YOUR RIGHTS UNDER STATE LAW

- Neither SUPERLIFT® nor your independent SUPERLIFT® dealer are responsible for any time loss, rental costs, or for any incidental, consequential or other damages you may have.
- This Limited Warranty gives you specific rights, and this is the only warranty SUPERLIFT® makes in connection with your product purchase. You may also have other rights that vary from state to state. For example, while all implied warranties are disclaimed herein, any implied warranty required by law is limited to the terms of our Limited Lifetime Warranty as described above. Some states do not allow limitations of how long an implied warranty lasts and / or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you. SUPERLIFT® neither assumes nor authorizes any retailer or other person or entity to assume for it any other obligation or liability in connection with this product or Limited Warranty.

IMPORTANT PRODUCT USE AND SAFETY INFORMATION / WARNINGS

As a general rule, the taller a vehicle is, the easier it will roll over. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall"; always use as wide a tire and wheel combination as feasible to enhance vehicle stability. We strongly recommend, because of rollover possibility, that the vehicle be equipped with a functional roll bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capabilities are decreased when significantly larger / heavier tires and wheels are used. Take this into consideration while driving. Also, changing axle gear ratios or using tires that are taller or shorter than factory height will cause an erroneous speedometer reading. On vehicles equipped with an electronic speedometer, the speed signal impacts other important functions as well. Speedometer recalibration for both mechanical and electronic types is highly recommended.

Do not add, alter, or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the SUPERLIFT® product purchased. Mixing component brands is not recommended.

WE WANT TO SEE YOUR RIDE...

Grab photos of your SUPERLIFT Equipped truck in various poses and in action.

Email pictures to us at sales@superlift.com

Tag us on Facebook: @superlift suspension systems

Tag us on Instagram: #superlift, #superliftsuspension, #superliftequipped

THANKS For Choosing SUPERLIFT...

For questions, technical support and warranty issues relating to this SUPERLIFT products, please contact SUPERLIFT directly.

SUPERLIFT SUSPENSION 300 Huey Lenard Loop Rd. West Monroe, Louisiana 71292 Phone: (318) 397-3000 Sales / Tech: (800) 551-4955 Fax: (318) 397-3040 SUPERLIFT.COM