



3651 N Highway 89 • Chino Valley, AZ 86323
(928) 636-7080 • www.p-a-g.net

DODGE RAM 1500 2 & 4WD GASOLINE ENGINES 3" BODY LIFT INSTALLATION INSTRUCTIONS 2006-2008 **KIT# 60173**

⚠ WARNING

Installation of a Performance Automotive Group body lift kit will change the vehicle's center of gravity and handling characteristics both on- and off-road. You must drive the vehicle safely! Extreme care must be taken to prevent vehicle rollover or loss of control, which could result in serious injury or death. Avoid sudden sharp turns or abrupt maneuvers and always make sure all vehicle occupants have their seat belts fastened.

⚠ WARNING

Before you install this kit, read and understand all instructions, warnings, cautions, and notes in this instruction sheet and in the vehicle owner's manual.

⚠ CAUTION

Proper installation of this kit requires knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle. We strongly recommend that a certified mechanic familiar with the installation of similar components install this kit.

⚠ WARNING

DO NOT combine suspension, body, or other lift devices. Use of vehicle with combined lifts may result in unsafe and/or unexpected handling characteristics.

NOTE

Front bumper tow hooks can NOT be used following the installation of this kit.

⚠ WARNING

This kit should only be installed on a vehicle that is in good working condition. Before you install the kit, thoroughly inspect the vehicle for corrosion or deformation of the sheet metal around the factory body mounts. If the vehicle is suspected to have been in a collision or misused, do not install this kit. Off-road use of your vehicle with this kit installed may increase the stress applied to the factory body mounts. We do not recommend that any vehicle with a body lift kit installed be involved in any extreme off-road maneuvers such as jumping. Failure to observe this warning may result in serious personal injury and/or severe damage to your vehicle.

⚠ WARNING

Many states and municipalities have laws restricting bumper heights and vehicle lifts. Consult state and local laws to determine if the changes you intend to make to the vehicle comply with the law.

⚠ WARNING

The installation of larger tires may reduce the effectiveness of the braking system.

⚠ WARNING

Always wear eye protection when operating power tools.

⚠ WARNING

Before you install this kit, block the vehicle tires to prevent the vehicle from rolling.

⚠ WARNING

Accidental deployment of the air bag can result in serious personal injury or death. To avoid accidental deployment during installation of the kit, the Supplemental Restraint System (SRS, or airbag) must remain deactivated. Do not allow anyone near the airbag during installation. Refer to the factory service manual or owner's manual for the recommended procedure to disable the SRS. After you install the kit, reactivate the SRS before driving the vehicle.

NOTE

Performance Automotive Group recommends using the Loctite® supplied in the kit on the threads of all kit nuts and bolts unless specified otherwise in these instructions.

Before Starting Installation

NOTE

Kit parts are prefaced by the word **kit** and appear in **bold** print.

1. Carefully read all warnings and instructions completely before beginning.
2. Verify all parts have been received in this kit by checking the parts list at the end of this document.

NOTE


If parts are missing from kit, please be prepared to provide the following information:

1. **Name** of purchase location
2. **Bar Code** on side of box
3. **Date** above bar code
4. **Date** inside box cover
5. **Inspector #** from inside box cover

3. **Only install this kit on the vehicle for which it is specified.** If anytime during the installation you encounter something different from what is outlined in the instructions, call technical support at (928) 636-7080.
4. Special tools needed:
 - a. Welder or access to a professional welding shop.
 - b. Die grinder, cut off wheel, sawzall, or similar tool capable of cutting metal.
5. Park vehicle on a clean, dry, flat, level surface and block tires so vehicle cannot roll in either direction.

Engine Compartment

1. Disconnect both battery cables. Disconnect negative cable first, then positive cable.




2. Airbag Fuse

NOTE

The location of the airbag fuse may vary; check the vehicle owner's manual.

- a. Remove fuse cover.
- b. Remove airbag fuse.



Prepare to Install Kit

Measurements

1. Measure and record distance between front bumper and fenders.

Driver Side _____ Passenger Side _____

2. Measure and record distance between rear bumper and bed

Driver Side _____ Passenger Side _____


3. Measure and record distance between cab and bed.

Driver Side _____ Passenger Side _____


Front of Vehicle

1. Front bumper


- a. **2007:** Remove six push clips and lower splash guard from bumper, core support, and fan shroud.



- b. Disconnect fog light harness at driver side of front bumper and pull connector off of front bumper, if equipped.




- c. Remove eight nuts and front bumper from frame horns.



Engine Compartment

1. Airbox


- a. Release four clips from airbox cover. Remove breather hose from airbox cover. Loosen clamp and airbox hose at intake housing.




- b. Remove airbox cover, base and filter from vehicle.

2. Radiator overflow and window washer reservoirs


a. Remove bolts, radiator overflow, and window washer reservoirs from fan shroud.



b. Disconnect and cap off overflow and washer hoses.




c. Remove two electrical connectors from reservoirs.




d. Remove radiator overflow and window washer reservoirs from fan shroud.

3. Fan shroud


a. Remove bolts and fan from fan clutch. Pull fan towards engine and rest fan on fan clutch shaft.



b. Remove power steering lines and clip from bottom of fan shroud.



c. Remove two bolts and fan shroud from radiator.




CAUTION
DO NOT DAMAGE radiator while removing fan shroud.

4. Automatic transmission cooler

- a. Remove clip and two automatic transmission cooler lines from engine block.

- c. Remove bolt and intermediate shaft from rack and pinion. Slide intermediate shaft up to separate from rack and pinion.




NOTE
Intermediate shaft may not separate from rack and pinion until cab is lifted.

- 6. Remove two heater hoses from clip on passenger side of firewall.

5. Steering Shaft



⚠ WARNING
Accidental deployment of the air bag can result in serious personal injury or death. To avoid accidental deployment during installation of the lift kit, the Supplemental Restraint System (SRS, or airbag) must remain deactivated. Do not allow anyone near the airbag during installation. Refer to the factory service manual or owner's manual for the recommended procedure to disable the SRS. After kit installation, the SRS must be reactivated before driving the vehicle.



- 7. Remove brake sensor harness from passenger and driver fender wells.

⚠ CAUTION
If the following step is not performed, the airbag clock-spring could be damaged. Do not turn the steering wheel while the steering shaft is disconnected.


- a. Strap steering wheel to prevent accidental movement.
- b. Mark intermediate shaft in relation to rack and pinion as shown.




Underside of Vehicle

1. Wire harnesses and brake lines


- a. Remove bolts and brake line brackets from driver side frame rail.



- b. Remove bolt and ground strap from driver side frame rail.




- c. Remove harness from driver side body mount bracket.




NOTE

The following procedures applies ONLY to automatic transmissions.

- d. **Automatic transmission models:** Remove transmission shifter cable from clip on driver side brake line.




- e. **Automatic transmission models:** Remove transmission wire harness from frame mount clip.



2. Parking brake cable


- a. Pull slack into parking brake cable. Attach locking pliers to parking brake cable to allow slack, if necessary.

b. Use expanding pliers to disconnect parking brake cable from junction.




c. Remove parking brake cable from driver side frame mount.


d. Remove six bolts and shift lever boot seal from floor.




e. Remove rubber cover from shift tower.



f. Remove four Torx bolts from shift tower mounting plate.



g. Remove shift lever from shift tower.




Inside of Vehicle

1. Manual transmission shift lever

a. Shift transmission into neutral.

b. Unscrew transmission shift lever from shift tower.




NOTE


Some of the bolts securing the center console to the floor are underneath the cup holder rubber inserts.

c. Remove bolts and center console from floor.

- h. Remove two plastic shift tabs, plastic ball, shim and mounting plate from shift lever.



- a. Remove bolt and ground strap from bed or cab.




NOTE

The following procedures apply only to vehicles with manual transfer cases.

3. Rear bumper

- a. Remove wire harness connectors from rear bumper.




Rear of Vehicle

1. Fuel filler


⚠ WARNING

Use extreme caution when working near fuel line(s) and fuel tank(s). Clean up spilled fuel immediately. Any spark could cause an explosion or fire resulting in serious personal injury and/or property damage.

- a. Remove fuel cap from fuel filler.
- b. Remove three bolts attaching fuel filler to body.




- b. Remove two screws and license plate.




2. Ground strap


c. Remove two bolts from bumper bracket and bed.




d. Remove two bolts from rear bumper and trailer hitch, if equipped.



e. Remove four nuts, two double bolt fasteners, and bumper from bumper brackets.




f. Remove four bolts and bumper brackets from frame.




4. Spare tire winch

a. Lower spare tire to ground and remove (see owner's manual for procedure).

b. Remove retaining clip and ratchet tube from spare tire winch.




c. Remove plastic ratchet tube guide from cross-member.



Install Kit


Cab

1. Prepare to lift cab from frame
 - a. Loosen, but **DO NOT REMOVE**, cab mounting bolts on driver side.



NOTE
The number of cab mounting bolts may vary with the length of the cab.

- b. Remove bolt from each cab mount on passenger side.



⚠ WARNING


Use extreme caution when lifting body from frame. To prevent serious personal injury, ensure the lifting device is securely placed. Keep your hands out from between the body and frame.

⚠ CAUTION

Continually check hoses, wires, lines, etc. to be sure that everything is flexing properly and not binding, or damage to the vehicle could result. Be especially careful of the a/c hoses at the fire wall, the belt pulley, and at the core support. Ensure brake lines stretch while lifting. Bending the lines to gain ample slack may be necessary. Be extremely careful not to kink the lines.

2. Cab passenger side

- a. Remove captive washers from each factory cab mount bolt.




- b. Position a hydraulic jack and a wood block under passenger side of cab (under the body seam). Slowly lift cab just enough to install a *kit block* on top of factory upper bushing.


⚠ WARNING

The *kit blocks* must be installed in addition to the factory upper and lower bushings. Installing the *kit blocks* without the factory upper and lower bushings could result in damage to the vehicle or serious personal injury.

- c. Place **kit blocks** (3" x 3") on metal cups and upper bushings on each cab mount.




- d. Lower cab onto **kit blocks** (3" x 3").
- e. Install **kit bolt** (12mm-1.75 x 180mm) into each cab mount. **DO NOT TIGHTEN.**



3. Cab driver side


- a. Repeat previous steps on driver side of cab.
- b. Set cab-to-bed spacing according to previous measurement.
- c. Remove each **kit bolt**, one at a time, and apply a few drops of **kit Loctite®** to threads. Install **kit bolt**, and captive washer. Tighten **kit bolts** to **55 ft. lbs.**



Bed


1. Prepare to lift bed from frame

- a. Loosen, but **DO NOT REMOVE**, bed mounting bolts on driver side.



NOTE
The number of bed mounting bolts may vary with the length of the bed.

2. Remove bolt from each bed mount on passenger side.



⚠ WARNING


Use extreme caution when lifting the bed from the frame. To prevent serious personal injury, ensure the lifting device is securely placed. Keep your hands out from between the bed and frame.

⚠ CAUTION


To prevent damage to the vehicle while lifting the bed, continually check hoses, wires, brake lines, etc. to ensure everything is flexing properly and not binding. Ensure clearance between bed and cab is maintained.

3. Bed passenger side

- a. Using a hydraulic jack and a wood block, slowly lift passenger side of bed a little more than 3".
- b. Place a **kit block** (3" x 3") rear frame mount.



- c. Place **kit blocks** (3" x 3") on two (or three) other frame mounts.




- d. Lower bed onto **kit blocks**.
- e. At rear bed mount, install **kit bolt** (12mm-1.75 x 120mm) and **kit washer** (7/16" USS). **DO NOT TIGHTEN**.
- f. At each other bed mount, install **kit bolt** (12mm-1.50 x 100mm) and **kit washer** (7/16" USS). **DO NOT TIGHTEN**.
- g. Repeat previous steps on driver side of bed.
- h. Set bed-to-cab spacing according to previous measurement.
- i. Remove each **kit bolt**, one at a time, and apply a few drops of **kit Loctite®** to threads. Install **kit bolt** with **kit washer** (7/16" USS). Tighten **kit bolts** to **55 ft. lbs.**


Rear of Vehicle

1. Spare tire winch


- a. Remove three bolts and spare tire winch from crossmember.




b. Using 9/16" drill bit, drill two mounting holes and remove mounting plate from spare tire winch.




d. Install spare tire winch onto **kit bracket** (winch) with two **kit bolts** (3/8" x 1"), four **kit washers** (3/8" USS), and two **kit nuts** (3/8" Nylock).



e. Remove two wire loom clips and wire harness from crossmember.




f. Install **kit bracket** (ratchet tube) onto crossmember with two **kit bolts** (1/4"-20 x 1"), four **kit washers** (1/4" SAE) and two **kit nuts** (1/4"-20 Nylock). Install plastic guide tube into **kit bracket** (ratchet tube).




NOTE
DO NOT DRILL THROUGH HOLE. Only drill until mounting plate is free from spare tire winch.


c. Install **kit bracket** (winch) and mounting plate onto crossmember with three bolts. Position plastic guide between winch and **kit bracket** (winch).




g. Install ratchet tube onto spare tire winch with retaining clip.




j. Install spare tire on vehicle (see owner's manual).




h. Install wire harness onto crossmember with *kit tie* (zip).



k. Install ground strap to cab with bolt.



i. Verify ratchet tube is visible through hole in bed and plastic ratchet tube guide. Adjust *kit bracket* (spare tire ratchet tube), if necessary.




2. Rear bumper

⚠ WARNING


The following procedure is intended only to enhance the appearance of the vehicle. The rear bumper will no longer be rated for towing of any kind. Towing with the rear bumper after it has been lifted can result in death, serious personal injury, or damage to the vehicle. Towing after the bumper has been lifted should be accomplished using a rated Class III receiver type hitch.

a. Apply a few drops of *kit Loctite*® to factory bolts. Install *kit bracket* (rear bumper, middle) on trailer hitch with two factory bolts. **DO NOT TIGHTEN.**





- b. Apply a few drops of *kit* **Loctite®** to factory bolts. Install *kit* **brackets** (rear bumper) onto frame with factory hardware. DO NOT TIGHTEN.


- d. Install rear bumper onto *kit* **bracket** (rear bumper, middle) with two *kit* **bolts** (7/16" x 1-1/2"), four *kit* **washers** (7/16" USS) and two *kit* **nuts** (7/16" Nylock). DO NOT TIGHTEN.



- c. Apply a few drops of *kit* **Loctite®** to factory bolts. Install rear bumper on *kit* **brackets** (rear bumper) with factory two double bolt fasteners and four nuts. DO NOT TIGHTEN.




- e. Install *kit* **brackets** (rear bumper) onto bumper with two factory bolts. DO NOT TIGHTEN.




- f. Align rear bumper to previous bed-to-bumper measurements. TIGHTEN all hardware.

g. Connect wiring harnesses to bumper.




h. Install license plate onto bumper with two factory screws.

a. Slide white retaining clip outward and remove vent hose from fuel filler assembly.



b. Remove hose clamp and fuel hose, vent hose and fuel filler assembly from vehicle.

c. Carefully cut metal vent tube as shown.




Underside of Vehicle

1. Crush blocks

⚠ WARNING
A certified welder should perform all welding.

a. Weld two **kit blocks** (3" crush) onto passenger side frame, below bed, where shown.




b. Repeat above step for driver side.


⚠ WARNING
Use extreme caution when working near the fuel lines and the fuel tank. Clean up spilled fuel immediately. A spark could cause an explosion or fire resulting in serious personal injury and property damage.

2. Fuel filler

- d. Install **kit extension** (vent, 1/4" x 3") between cut ends of metal vent tube with two **kit clamps** (#6 hose). DO NOT TIGHTEN.




- e. Install fuel filler assembly onto fuel and vent hoses. Push in white retaining clip to secure vent hose.
- f. Install fuel filler assembly on bed with three bolts. Install fuel cap.




- g. Adjust fuel filler hoses as necessary. TIGHTEN all hose clamps.

3. Parking brake cable

- a. Using **kit bracket** (parking brake) as a template, drill a 5/16" hole in bottom of factory parking brake mount on driver side frame rail.



- b. Install **kit bracket** (parking brake) onto factory parking brake mount with one **kit bolt** (5/16" x 1"), two **kit washers** (5/16" USS) and one **kit nut** (5/16" Nylock). DO NOT TIGHTEN.
- c. Install **kit bracket** (parking brake) onto factory parking brake mount with one **kit bolt** (7/16" x 1"), two **kit washers** (7/16" SAE) and **kit nut** (7/16" Nylock). TIGHTEN all hardware.




- d. Route front parking brake cable through largest hole in **kit bracket** (parking brake) and connect parking brake cable.

4. Ground strap


- a. Install **kit bracket** (3" ground, big hole) to frame on driver side with factory bolt.

- b. Install ground strap onto **kit bracket** (3" ground, big hole) with **kit bolt** (1/4"-20 x 1"), two **kit washers** (1/4"-20 x 1") and **kit nut** (1/4"-20 Nylock).

- b. Install brake line bracket onto to **kit brackets** (C-shaped) with two **kit bolts** (1/4" x 1"), four **kit washers** (1/4" SAE), and two **kit nuts** (1/4" Nylock).




- 5. Install wire harness to body mount bracket on driver side with clip.




- 6. Brake line bracket

- a. Install two **kit brackets** (C-shaped) onto driver side frame with two bolts.



- 7. Install transmission wire harness on frame mount clip.



Inside of Vehicle

⚠ WARNING


DO NOT DAMAGE any of the parts attached to the shift levers during cutting and/or welding. Damage to the shift lever equipment could result in serious injury or property damage.

⚠ WARNING


A certified welder should perform all welding.

- 1. Manual transmission shift lever


- a. Scribe a line along side of transmission shift lever (below lowest bend). Cut lever into two pieces and deburr as necessary.




- b. Scribe a line along side of *kit extension* (shift lever). Position *kit extension* between two pieces of transmission shift lever. Ensure scribed lines on *kit extension* and transmission shift lever align. Weld *kit extension* into place.




- c. Grind welded surfaces smooth in order to install mounting plate and shim to shift lever.




- d. Install two plastic shift tabs, plastic ball, shim and mounting plate onto shift lever.




- e. Install shift lever onto shift tower with four Torx bolts.




- f. Install rubber cover onto shift tower.



- g. Install shift lever boot seal onto floor with six bolts.



- h. Install center console onto floor with bolts.
- i. Screw transmission shift lever onto shift tower lever.
- j. Install bolts securing center console to floor.



- k. Replace rubber cup holder inserts into center console.
- l. Check transmission shift lever operation. Ensure there is complete engagement in all gears.

Engine Compartment


1. Steering shaft



⚠ WARNING


Verify the steering extension is securely installed as specified in the instructions. Failure to do so may cause steering malfunction, resulting in property damage or serious personal injury.

- a. Install **kit extension** (steering) in position on rack and pinion. Ensure marks on rack and pinion and intermediate shaft are aligned.




- b. Install intermediate shaft on **kit extension** (steering), ensuring marks on intermediate shaft and rack and pinion are aligned.
- c. Apply a few drops of **kit Loctite®** to factory bolt and **kit bolt** (3/8" x 1-1/4" Allen head).
- d. Install and TIGHTEN bolts to **33 lb.-ft.**

2. Install two heater hoses into clip on passenger side of firewall.




3. If possible, install brake sensor harness on passenger and driver fender wells.




b. Cut fan shroud along marked lines in two halves.

c. Remove mounting tab from lower half of fan shroud as shown.




4. Fan shroud

a. Mark a line on fan shroud as shown. Ensure line is exactly as appears below.




d. Position *kit bracket* (fan shroud, passenger) on outside upper fan shroud. Using *kit bracket* (fan shroud, passenger) as a template, mark and drill a 1/4" hole corresponding to each hole on *kit bracket* (fan shroud, passenger). DO NOT DRILL lower portion of fan shroud at this time.



e. Position **kit bracket** (fan shroud, driver) on outside upper fan shroud. Using **kit bracket** (fan shroud, driver) as a template, mark and drill a 1/4" hole corresponding to each hole on **kit bracket** (fan shroud, driver). DO NOT DRILL lower portion of fan shroud at this time.



g. Position lower portion of fan shroud with **kit brackets** (fan shroud) 3" from upper portion of fan shroud as shown.




CAUTION

Insert **kit bolts** into fan shroud so threads are away from fan, if possible, to avoid contact between fan and **kit bolts**.

f. Install **kit brackets** (fan shroud) onto upper portion of fan shroud with **kit bolt** (1/4"-20 x 1"), two **kit washers** (1/4" SAE) and **kit nut** (1/4"-20 Nylock) at each drilled hole location. Snug, but DO NOT TIGHTEN.




h. Using **kit brackets** (fan shroud) as templates, mark and drill a 1/4" hole corresponding to each hole on **kit brackets** (fan shroud).




- i. Install **kit brackets** (fan shroud) onto lower portion of fan shroud with **kit bolt** (1/4"-20 x 1"), two **kit washers** (1/4" SAE) and **kit nut** (1/4"-20 Nylock) at each drilled hole location. Snug, but DO NOT TIGHTEN.

- k. Attach **kit cover** (fan shroud) to upper and lower portions of fan shroud with **kit bolt** (1/4"-20 x 1"), two **kit washers** (1/4" SAE) and **kit nut** (1/4"-20 Nylock) at each drilled hole location. Snug, but DO NOT TIGHTEN.




- j. Install **kit gap guard** (fan shroud) inside upper and lower portions of fan shroud. Using **kit cover** (fan shroud) as a template, mark and drill a 1/4" hole corresponding to each hole on **kit cover** (fan shroud).




- l. Ensure 3" spacing between upper and lower portions of fan shroud. Tighten all hardware.


NOTE
It may be possible to use some of the existing holes drilled in the previous step to attach **kit gap guard** (fan shroud) to upper and lower portions of the fan shroud.



- m. Remove two bolts and power steering cooler from bottom of radiator. Allow power steering cooler to hang under radiator. DO NOT DISCONNECT power steering cooler lines.




- n. Install fan shroud onto radiator. Ensure fan shroud tabs are seated completely in radiator slots. Install fan shroud to radiator with two factory bolts.




⚠ WARNING
 Rotate fan and verify *kit bolts* (1/4" x 1") are NOT contacting fan. Any parts contacting fan will cause severe fan, fan clutch, radiator or other vehicle damage and/or personal injury

- o. Pull fan towards radiator off fan clutch shaft. Install fan onto fan clutch with bolts.




- p. Install two automatic transmission cooler lines on engine block with clip.




5. Power steering cooler

- a. Position two *kit spacers* (1-1/2" cooler) in bottom of radiator.
- b. Install two *kit brackets* (2" S-shaped) onto bottom of radiator, through *kit spacers* (1-1/2"), with two factory bolts. DO NOT INSTALL factory nuts on factory bolts at this time.




- c. Install power steering cooler onto two *kit brackets* (2" S-shaped) with two *kit washers* (1/4" SAE) and two *kit nuts* (1/4"-20 Nylock). DO NOT TIGHTEN.




6. Lower fan shroud block off plate

- a. Install **kit plate** (fan shroud, driver) and **kit plate** (fan shroud, passenger) together with two **kit bolts** (1/4"-20 x 1"), four **kit washers** (1/4" SAE) and two **kit nuts** (1/4"-20 Nylock). DO NOT TIGHTEN.




- b. Install **kit plates** (fan shroud) onto rear of radiator and front of lower fan shroud as shown. Power steering cooler bolts from previous step will align with holes in top of **kit plates** (fan shroud). Install **kit plates** with factory power steering cooler bolts and nuts. DO NOT TIGHTEN.
- c. Using **kit plates** (fan shroud) as a template, drill five 15/64" holes in lower fan shroud edge.
- d. Install **kit plates** (fan shroud) to fan shroud with five **kit clips** (push).




- e. TIGHTEN two **kit bolts** (1/4"-20 x 1") attaching **kit plate** (fan shroud, driver) to **kit plate** (fan shroud, passenger).
- f. TIGHTEN all power steering cooler and **kit plates** (fan shroud) hardware.

7. Radiator overflow and window washer reservoirs


- a. Install radiator overflow and window washer reservoirs onto fan shroud.
- b. Connect two electrical connectors on reservoirs.



- c. Install radiator overflow and window washer reservoirs onto fan shroud with bolts.



- d. Connect overflow and washer hoses.





8. Airbox


- a. Install airbox cover, base and filter on vehicle.

- b. Install airbox cover onto airbox base with four clips. Install breather hose on airbox cover. TIGHTEN airbox hose clamp at intake housing.

- c. Remove two lower crush zones from front bumper.



- d. Mark and cut driver and passenger side lower front crush zones as shown.




Front of Vehicle

- 1. Front bumper


⚠ CAUTION

Factory supplied front two hooks CAN NOT be used, if equipped.


- a. Remove ten nuts and two front bumper brackets from front bumper.
- b. Remove eight studs from two front bumper brackets.




e. Mark and cut two front bumper frame horns as shown.



f. Mark and cut driver and passenger side front bumper as shown.




g. Mark and cut driver and passenger side front bumper as shown.




h. Install two lower front crush zones onto front bumper.




i. Install eight studs into two *kit brackets* (front bumper).




j. Apply a few drops of *kit Loctite*® onto threads of studs and install two *kit brackets* (front bumper) onto front bumper with ten nuts. If necessary trim front bumper to fit *kit brackets* (front bumper).



k. Apply a few drops of *kit Loctite*® onto threads of studs and install front bumper onto two frame horns with eight nuts. **DO NOT TIGHTEN.**




l. Position front bumper to frame. Ensure both edges of fender well fit on backside of bumper edge.




m. Adjust bumper to fender until previous bumper-to-fender measurement is obtained. **TIGHTEN** all hardware.

n. Connect fog light harness at driver side of front bumper and install onto front bumper, if equipped.



- o. **2007:** Install four push clips and lower splash guard on bumper, core support, and fan shroud.



After Completing Installation


Engine Compartment

1. Airbag fuse

⚠ NOTE

The location of the airbag fuse may vary; check the owner's manual.

- a. Install airbag fuse(s).
 - b. Install fuse cover.
2. Connect both battery cables. Connect positive cable first, then negative cable.



Miscellaneous

1. Apply *kit label* (warning) to dashboard in plain sight of all vehicle occupants.
2. Check all fasteners to ensure they are tight.
3. Ensure all wires, hoses, cables, etc. are properly connected and there is ample slack.

Dynamic Vehicle Check

1. Test-drive vehicle. Check steering in both directions to ensure that there is no bind. Check operation of clutch, brake system, and parking brake. Check operation of transmission and transfer case. Ensure there is full engagement in all gears and 4WD ranges. Check battery connections and electrical component operations.

⚠ WARNING

Retorque all fasteners after 500 miles and after off road use. All body lift components should be visually inspected and fasteners retorqued during routine vehicle servicing.

⚠ CAUTION

Performance Automotive Group does not recommend any particular wheel and tire combinations for use with its body lifts and cannot assume responsibility for the customer's choice of wheels and tires. Refer to your owner's manual for recommended tire sizes and warnings related to the use of oversized tires. Larger wheel and tire combinations increase stress and wear on steering and suspension components, which leads to increased maintenance and higher risk for component failure. Larger wheel and tire combinations also alter speedometer calibration, braking effectiveness, center of gravity, and handling characteristics. Consult an experienced local off road shop to find what wheel and tire combinations work best with your vehicle.


NOTE

All warranty information, instruction sheets, and other documents regarding the installation of this product must be retained by the vehicle owner. Information contained in the instructions and on the warranty card will be required for any warranty claims. The vehicle owner needs to understand the modifications made to the vehicle and how they affect vehicle handling and performance. Failure to provide the customer with this information can result in damage to the vehicle and severe personal injury.

Accessories

The following accessories are also available:

Kit # 6626: Gap Guards



⚠ NOTE

Depending on the vehicle configuration (automatic or manual transmission, 2WD or 4WD, cab length, bed length, etc.), some parts may not be used.

Kit Parts List

Qty.	Description
16	Block (3" x 3" spacer)
4	Block (3" crush)
32	Bolt (1/4"-20 x 1")
1	Bolt (3/8"-16 x 1-1/4" Allen head)
2	Bolt (3/8" x 1")
6	Bolt (12mm-1.50x 100mm)
2	Bolt (12mm-1.75 x 120mm)
10	Bolt (12mm-1.75 x 180mm)
1	Bolt (5/16" x 1")
2	Bolt (7/16" x 1-1/2")
1	Bolt (7/16" x 1")
2	Bracket (2" S-shaped)
2	Bracket (C-shaped)
1	Bracket (fan shroud, driver)
1	Bracket (fan shroud, passenger)
1	Bracket (front bumper, driver)
1	Bracket (front bumper, passenger)
1	Bracket (ground strap, big hole)
1	Bracket (parking brake)
1	Bracket (rear bumper, driver)
1	Bracket (rear bumper, passenger)
1	Bracket (rear bumper, middle)
1	Bracket (ratchet tube)
1	Bracket (winch)
2	Clamp (#6 hose)
5	Clip (push)
1	Gap guard (fan shroud)
1	Extension (1/4" x 3" hose)
1	Extension (steering)
1	Extension (shift lever)
1	Label (logo)
1	Label (warning)
1	Label (warning, rear bumper)
1	Loctite® (6ml bottle)
37	Nut (1/4" Nylock)
1	Nut (5/16" Nylock)
2	Nut (3/8" Nylock)
2	Nut (7/16" Nylock)
1	Plate (fan shroud, driver)
1	Plate (fan shroud, passenger)
2	Spacer (1-1/2")
1	Tie (zip)
64	Washer (1/4" SAE)
2	Washer (5/16" USS)
4	Washer (3/8" USS)
2	Washer (7/16" SAE)
12	Washer (7/16" USS)