



WJ JEEP ADJ FR TRACK ROD FOR 2"-6" LIFT

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the kit content list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have the necessary tools to install this kit.

PRODUCT USE INFORMATION

Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Tools Needed:

15mm Socket / Wrench
18mm Socket / Wrench
19mm Socket / Wrench

Torque Specs:

Size	Grade 5	Grade 8
7/16"	45 ft/lbs	60 ft/lbs
	Class 8.8	Class 10.9
12MM	55ft/lbs	75ft/lbs



Kit Contents:



Track Rod Body
Heim End

Poly Bag Containing:


Heim End Spacers (2)
Bushings (2)
Sleeve
12mm x 65mm Bolt
Flat Washer
12mm Lock nut
Jam Nut

INSTALLATION INSTRUCTIONS

1. Place the vehicle on a level surface and chock the rear wheels.
2. Remove the track bar using a 19mm wrench/socket from the driver side mount. **See Photo 1.**
3. Remove the track bar from the axle using a 15mm wrench as shown in **Photo 2.** Retain the axle hardware for reuse.



4. Lubricate the supplied bushings / sleeves with a lithium grease and assemble the bushings and sleeves in the track bar end.
5. Install the track bar on the axle mount with the factory hardware. **See Photo 3.** Do not tighten at this time.
6. Assemble the spacers on the heim joint as shown in **Photo 4.**



7. Make sure the body of the vehicle is centered over the axle and adjust the end as needed and install the end on the frame with the supplied 12mm x 65mm hardware. Do not tighten at this time. **See Photo 5.**
8. After making sure the body is centered, tighten the jam nut using a 1 1/8" wrench on the track rod end.
9. Tighten the frame end with a 18mm & 19mm wrench and on the axle end with a 15mm socket.



Thank you for choosing Rough Country for your suspension needs.

**ROUGH
COUNTRY**
SUSPENSION SYSTEMS