



## FORD 2005-22 F-250 Vertex Coilover Conversion

**Thank you for choosing Rough Country for all your vehicle needs.**

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Periodically check all hardware for tightness.

**KIT CONTENTS:**

- Upper Coil Over Mount x2
- Lower Coil Over Mount x2
- Brake Line Relocation Bracket x2
- Driver Vertex x1
- Passenger Vertex x1
- Front Shocks x2

**TOOLS NEEDED:**

- 10mm Wrench or Socket
- 18mm Wrench or Socket
- 21mm Wrench or Socket
- 22mm Wrench or Socket
- 7/16 Wrench or Socket
- 9/16 Wrench or Socket
- 30mm Socket
- Drill Motor
- .406 Drill Bit
- Reciprocating Saw
- Sander
- Color Match Frame Paint
- Paint Pen
- Jack Stands
- Jack

**HARDWARE INCLUDED:**

- 3/8-16 x 1.25 Hex Head Bolt x8
- 3/8" Washer x8
- 3/8-16 Flange Lock x8
- 14mm-2.0 x 40mm x2
- 14mm Lock Washer x2
- 14mm Flat Washer x10
- 14mm-2.0 x 75mm x4
- 14mm-2 Nylock Nut x4
- 1/4-20 x 1 Hex Head Bolt x6
- 1/4-20 Nylock Nut x6
- 1/4" Flat Washer x6

**Torque Specs:**


Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs







## INSTALLATION INSTRUCTONS


1. Lift up the front of the vehicle using a jack, place jack stands under the frame and lower the vehicle.
2. Remove the wheels and tires from the vehicle.
3. Support the axle using a jack and remove the front sway link nut from each side of the vehicle using an 18mm socket. **See Photo 1.**
4. Remove the trackbar bolt and bar from the frame mount using a 30mm socket.
5. Remove the brake line bracket from the axle mount using a 10mm socket.
6. Disconnect the abs line from the radius arm.
7. Remove the lower shock bolt using an 21mm socket. **See Photo 2.**
8. Remove the upper shock hard ware using a 21mm wrench, then remove the shock from the vehicle.





9. Remove the brake line bracket from the frame using a 10mm socket. **See Photo 3.**
10. Lower the jack down and remove the coil spring from the vehicle. **See Photo 4.**





11. Remove the coil spring isolator. **See Photo 5.**
12. Cut along the top of the coil spring mount, removing the coil spring centering mount. Using a reciprocating saw. **See Photo 6.**




13. Sand the trimmed are flush with the coil mount and touch any sanded areas with color match spray paint. **See Photos 7 and 8.**





14. Using a paint pen to transfer the hole orientation of the coil mount. **See Photo 9.**  
15. Use a 13/32" bit to drill each marked hole in the coil mount. **See Photo 10.**





16. Install (2) of the supplied 3/8-16 bolts, and (2) 3/8" Washers into the upper bracket and place the coil over mount to the bottom of the coil seat. **See Photos 11 and 12.**  
17. Secure the brackets using (2) of the supplied 3/8 Flange locks nuts. Tighten using a 9/16 wrench and socket.




18. Remove the lower spring seat using a 21mm socket. **See Photo 13.**  
19. Install the lower spring seat onto the axel. Then secure using (1) 14mm hex head bolt (1) 14mm Lock washer and (1) 14mm Flat washer. Tighten using a 22mm socket. **See Photo 14.**




20. Install brake line bracket to front side of the axle mount using (1) 1/4-20 x 1" Hex head bolt (2) 1/4" Flat washers and (1) 1/4-20 Hex nut. Tighten the bracket parallel with the axle bracket using a 7/16 wrench and socket. **See Photo 15.**  
21. Install the Vertex Coilover into the upper mount. Secure using (1) 14mm x 40mm Hex head bolt (2) 14mm Washers and (1) 14mm-2.0 Nylock nut. Tighten using a 22mm wrench and socket. **See Photo 16.**




22. Raise the axle up and install the lower coilover mount into the bracket. Secure using (1) 14mm x 40mm Hex head bolt (2) 14mm Washers and (1) 14mm-2.0 Nylock nut. Tighten using a 22mm wrench and socket. **See Photo 17.**  
23. Place the reservoir onto the mount and secure using (2) clamps around the mount and reservoir. Tighten using a flat bit driver. **See Photo 18.**



24. Secure the vacuum line to the rear of the axle bracket using (1) 1/4-20 x 1" Hex head bolt(2) 1/4" Flat washers and (1) 1/4-20 Hex nut. Tighten the bracket parallel with the axle bracket using a 7/16 wrench and socket. **See Photo 19.**
25. Secure brake line bracket to front bracket installed onto the axle bracket using (1) 1/4-20 x 1" Hex head bolt(2) 1/4" Flat washers and (1) 1/4-20 Hex nut. Tighten the bracket using a 7/16 wrench and socket. **See Photos 20 and 21.**




**Secure the vacuum line to the axle bracket.**




**Secure the brake line bracket.**

26. Install upper shock mount using the bushing stack supplied. Tighten the nut using a 22mm socket. **See Photo 22.**




**Secure the brake line bracket.**




**Install the upper shock mount.**

27. Install lower shock eyelet into axle mount. Secure using OE bolt, tightening using an 19mm socket. **See Photo 23.**
28. Install the wheels and tires, remove the vehicle from the jack stands and lower onto the ground.
29. Connect the track bar into the frame mount, securing with the OE bolt. Tighten using a 30mm socket. **See Photo 24.**



**Install the lower shock eyelet to axle mount.**



**Connect the track bar.**

30. Connect the sway links to the sway bar and secure using the OE nuts. Tighten using a 18mm socket.
31. Install the brake line into the frame mount using the OE bolt. Tighten using a 10mm socket.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

